Propellers
F210-Z-01

Motor fixed plate
F210-Z-02


Battery fixed plate
F210-Z-03

Reinforcement plate
F210-Z-04

Soleplate A
F210-Z-05

Soleplate B
F210-Z-06

Left side panel
F210-Z-07

Right side panel
F210-Z-08

Skid landing
F210-Z-09

Battery fixing board
F210-Z-10

PCB fixing mount
F210-Z-11

Headlight lamp holder
F210-Z-12

Support frame
F210-Z-13

Receiver antenna fixing mount
F210-Z-14

Camera guard
F210-Z-15

Camera fixing mount
F210-Z-16

Front support frame
F210-Z-17

Headlight lampshade
F210-Z-18

Fixing circular
F210-Z-19

Screw set
F210-Z-20

Brushless motor(CW)(WK-WS-28-014A)
F210-Z-21

Brushless motor(CCW)(WK-WS-28-014A)
F210-Z-22

Brushless ESC(CW)
F210-Z-23

Brushless ESC(CCW)
F210-Z-24


DEVO-RX713 Receiver
F210-Z-25

Main control board
F210-Z-26


TX5825(FCC) Transmitter
F210-Z-27


TX5824(CE) Transmitter
F210-Z-28


Power board
F210-Z-29


OSD
F210-Z-30

HD mini camera(700TVL)
F210-Z-31

Headlight
F210-Z-32

Taillight
F210-Z-33

5.8G Mushroom antenna
F210-Z-34

Li-po battery(14.8V 1300mAh 40C (4S))
F210-Z-35

Velcro strap
Runner 250-Z-27

Battery anti-slip mat
Runner 250-Z-30

Main controller flexible PCB
Runner 250(R)-Z-24

GA009 Charger
GA009