









# BLADE

ALL IN ONE FLIGHT MODULE



 Different modules have different wiring definitions, please refer to the actual. This illustration is for reference only.



 Analog VTX and digital VTX cannot be used at the same time.  
The HD-UNIT module is powered directly from the battery.

